


C1750: TRANSMISSION CONTROL M...**CONNECTOR C1750: TRANSMISSION CONTROL MODULE (TCM) (CONNECTOR VIEWS)****Connector:**
C1750**Description**
TRANSMISSION
CONTROL MODULE (TCM)**Color**
BK**Harness**
15525**Base Part #**
12B565**Service Pigtail**

Not Available



Pin	Circuit Gauge	Circuit Function	Qualifier
1	CBB72 (GN-VT) 18	FUSE - 72 OR CIRCUIT BREAKER	
2	CET25 (BU-GN) 18	CTRL MOD. - POWERTRAIN # TRANSMISSION SOLENOID POWER CONTROL (TSPC)	
3	CET49 (BN) 20	CTRL MOD. - POWERTRAIN # TRANSMISSION SOLENOID POWER CONTROL TCC	
4	CET09 (YE-VT) 20	CTRL MOD. - POWERTRAIN # SOLENOID PRESSURE CONTROL SSPC-E (L/R)	
5	CET08 (BN-WH) 20	CTRL MOD. - POWERTRAIN # SOLENOID PRESSURE CONTROL SSPC-D (DIR)	
6	CET07 (GY-OG) 20	CTRL MOD. - POWERTRAIN # SOLENOID PRESSURE CONTROL SSPC-C (INT)	
7	CET06 (GN-BN) 20	CTRL MOD. - POWERTRAIN # SOLENOID PRESSURE CONTROL SSPC-B (O.D)	
8	CET05 (BU-GN) 20	CTRL MOD. - POWERTRAIN # SOLENOID PRESSURE CONTROL SSPC-A (COAST)	
9	GD120 (BK-GN) 18	GROUND - FENDER FRONT LEFT	
10	*	*	Not Used
11	*	*	Not Used
12	*	*	Not Used
13	*	*	Not Used
14	*	*	Not Used
15	*	*	Not Used
16	*	*	Not Used
17	*	*	Not Used
18	*	*	Not Used
19	*	*	Not Used
20	LE111 (VT-GN) 20	CTRL MOD. - POWERTRAIN # BUFFERED POWER	

SHIPPY SENSORS

			SOFT-LOCK SENSORS (VBPWR)
21	*	*	Not Used
22	CET50 (WH- OG)	20	CTRL MOD. - POWERTRAIN # TRANSMISSION LINE PRESSURE CONTROL (LPC)
23	CLS28 (BU- WH)	20	CTRL MOD. - POWERTRAIN # REVERSE LAMP CONTROL RELAY (RLC)
24	*	*	Not Used
25	*	*	Not Used
26	*	*	Not Used
27	CLS05 (BU- GY)	20	CTRL MOD. - PARK
28	*	*	Not Used
29	*	*	Not Used
30	CET21 (GN- WH)	20	CTRL MOD. - POWERTRAIN # TRANSMISSION RANGE OUTPUT NEUTRAL (TRO- N)
31	CBB72 (GN- VT)	18	FUSE - 72 OR CIRCUIT BREAKER
32	*	*	Not Used
33	GD120 (BK- GN)	18	GROUND - FENDER FRONT LEFT
34	*	*	Not Used
35	*	*	Not Used
36	*	*	Not Used
37	*	*	Not Used
38	*	*	Not Used
39	*	*	Not Used
40	*	*	Not Used
41	GD120 (BK- GN)	18	GROUND - FENDER FRONT LEFT
42	*	*	Not Used
43	*	*	Not Used
44	*	*	Not Used
45	CET22 (GY- BN)	20	CTRL MOD. - POWERTRAIN # TRANSMISSION RANGE OUTPUT PARK (TRO-P)
46	RE406 (GY- VT)	18	CTRL MOD. - POWERTRAIN # SIGNAL RETURN
47	VDB04 (WH- BU)	20	CONNECTOR - DIAGNOSTIC # CAN BUS HIGH SPEED HIGH
48	VDB05 (WH)	20	CONNECTOR - DIAGNOSTIC # CAN BUS HIGH SPEED LOW
49	RET24 (BN- BU)	18	CTRL MOD. - POWERTRAIN # TRANSMISSION RANGE SIGNAL RETURN (TRO-N)

			(IRGND)
50	VET33 (WH-OG)	18	SENSOR - TURBINE/TRANSMISSION SHAFT SPEED (TSS)
51	RET04 (YE-OG)	20	CTRL MOD. - POWERTRAIN # SENSOR OUTPUT SHAFT SPEED (OSS)
52	VE744 (GY-BN)	18	SENSOR - INTERMEDIATE SHAFT SPEED (ISS)
53	CAT15 (BN-YE)	18	SWITCH - TOW MODE CONTROL (TOWS)
54	VET27 (BN-YE)	20	SENSOR - TRANSMISSION FLUID TEMPERATURE (TFT)
55	*	*	Not Used
56	*	*	Not Used
57	*	*	Not Used
58	*	*	Not Used
59	*	*	Not Used
60	SBB37 (GY-RD)	18	FUSE - 37 OR CIRCUIT BREAKER

 nbsp;

□

This publication contains material that is reproduced and distributed under a license from Ford Motor Company. No further reproduction or distribution of the Ford Motor Company material is allowed without the express written permission of Ford Motor Company.

Copyright 2007 - 2014 Service Repair Solutions, Inc.